



MICROFIBER CLEANING SYSTEMS

PRE-TREAT SYSTEM

MOST FREQUENT USE

RETAIL



HOSPITALITY



CLEANING CONTRACTORS



EDUCATION



LEDGES



STAINLESS STEEL



FLOORBOARDS



PRE-TREAT

The Pre-Treat system works to reduce cross-contamination. 1.5 gallons of water along 1 to 2 ounces of chemical can clean up to 10,000 square feet. With the system, there is no dirty water to dispose, no re-filling of mop buckets, a reduction in potential injuries and absenteeism and the mops can be laundered up to five hundred times.



Solution: Measure the recommended amount of solution (refer to the chart below for the right dilution).



Seal Buckets: Seal buckets with lids and ensure that all corners are tight and properly sealed.



Load Buckets: Load bucket with microfiber mops or pads with the microfiber side facing down.



Turn Buckets: Flip buckets over and allow to soak for fifteen minutes.



Add Solution: Pour solution slowly and evenly over the mops or pads.



Install Mop or Pad: Turn bucket over and remove lid. Install mop to mop frame or pad to pad frame.

MOPS	CLOTHS	PADS	18 inch (6 gallon bucket)	10 inch (3.5 gallon bucket)
		10 pads		
6 mops		12 pads	.37 gallons/ 1.4 liters	.2 gallons/ .75 liters
9 mops		18 pads	.50 gallons/ 1.9 liters	.3 gallons/ 1.2 liters
12 mops		24 pads	.75 gallons/ 2.8 liters	.4 gallons/ 1.5 liters
18 mops		36 pads	1.0 gallons/ 3.8 liters	.6 gallons/ 2.25 liters
21 mops			1.25 gallons/ 4.7 liters	.75 gallons/ 2.8 liters
24 mops			1.50 gallons/ 5.6 liters	.85 gallons/ 3.2 liters



IPC Eagle Corporation
 3650 Dodd Road Eagan, MN 55123
 800-486-2775
 info@ipceagle.com